
INSTALLATION MANUAL

For the most current release of this manual, please visit our website at **cogan.com**

V.2015.1





Product	Pre-Engineered Floor Decking System
Sub-product	Handrail


- 3 Types of handrail available: 2 rails, 3 rails and 1 rail with wire mesh panels.
- Top of handrail at standard 42" high.
- Uprights are side or top mounted.





cogan.com

















ø3/8"x3 1/2" BOLT Ø3/8" x 2 3/4" ANCHOR

UPRIGHT POSTS






DETAIL A (REINFORCEMENT ANGLES)

 $\emptyset 3/8$ " x 3 1/2" BOLTS ARE USED WHEN CONNECTING TO THE HANDRAIL UPRIGHT WITH OR WITHOUT COGAN'S REINFORCEMENT SINGLE ANGLE. USE 2 WASHERS PER BOLT.

ø3/8" x 1" BOLTS ARE USED WHEN CONNECTING COGAN'S REINFORCEMENT SINGLE ANGLE TO CHANNEL.

SINGLE CHANNELS AND SINGLE ANGLES

CI6XII.5 - CI6XIO.3




DETAIL B (REINFORCEMENT ANGLES)


 $\emptyset 3/8" \times 1 3/4"$ BOLTS ARE USED WHEN CONNECTING COGAN'S REINFORCEMENT WELDED ANGLE TO CHANNEL THAT ARE BACK TO BACK AND ON THE TOP OF ONE OF THE BACK TO BACK CHANNEL.

BACK TO BACK CHANNELS AND WELDED ANGLES


<u>CIGXII.5 - CIGXIO.3 AND CI4X9.3 - CI4X8.1 AND CI2X7.4</u>




COGAN'S REINFORCEMENT ANGLES ARE NOT NEEDED FOR CIOXG.7 AND C8X5.4 OR ANY I-BEAMS




DETAIL C (INSTALLATION ON TOP OF CONCRETE FLOORING)




DETAIL D (CONNECTION WITH EXISTING PRE-ENGINEERED FLOOR DECKING SYSTERM-CORRUGATED STEEL DECK FLOORING)






FLOORING








REFER TO FLOORING SECTION IN THE INSTALLATION MANUAL FOR COMPLETE DETAILS

HANDRAIL TUBE / WIRE MESH PANNEL AND ATTACHEMENT CLIP











WIRE MESH PANNEL



"Z" CLIP FOR EXTENSION POST



SIDE VIEW

